5 Port Solenoid Valve Series VQZ1000/2000/3000

Rubber Seal Metal Seal



Compact, High Flow

	Value width	Flow char	Outline allow	
Series	(mm)	Metal seal C [dm ³ /(s·bar)]	Rubber seal C [dm³/(s·bar)]	Cylinder size
VQZ1□2□	10	0.54	0.71	to ø63
VQZ2□2□	15	1.4	1.6	to ø80
VQZ3□2□	18	2.4	3.2	to ø100
VQZ1□5□	10	0.70	1.3	to ø63
VQZ2□5□	15	1.9	2.3	to ø80
VQZ3□5□	18	3.0	4.6	to ø100
	VQZ1 2 VQZ2 2 VQZ3 2 VQZ1 5 VQZ2 5	VQZ1 2 10 VQZ2 2 15 VQZ3 2 18 VQZ1 5 10 VQZ2 5 15	Series Valve width (mm) Metal seal C [dm³/(s·bar)] VQZ1□2□ 10 0.54 VQZ2□2□ 15 1.4 VQZ3□2□ 18 2.4 VQZ1□5□ 10 0.70 VQZ2□5□ 15 1.9	Series Valve width (mm) Metal seal C [dm³/(s·bar)] Rubber seal C [dm³/(s·bar)] VQZ1 2 10 0.54 0.71 VQZ2 2 15 1.4 1.6 VQZ3 2 18 2.4 3.2 VQZ1 5 10 0.70 1.3 VQZ2 5 15 1.9 2.3

Flow characteristics: $4/2 \rightarrow 5/3$ (A/B \rightarrow R1/R2)



VFS

VFR

VQ7

Option

Metal Seal / Rubber Seal **5 Port Solenoid Valve** Series VQZ1000/2000/3000



Series	Response speed	Service life	Accuracy			
VQZ1000	17 ms	200				
VQZ2000	18 ms	million	±2 ms			
VQZ3000	21 ms	cycles				

Metal seal, single solenoid with light/surge voltage suppressor, according to SMC life test conditions.

Body ported

Both 3 and 5 port valves can be mounted on the same manifold.



Base mounted Built-in one-touch fittings for easier piping Easy replacement of clip type one-touch fitting.

• DIN rail mounting is available.



Base mounted Body ported Fitting assembly Clip Clip /Clip Fitting assembly VQZ3000 VQZ1000/2000

- Enclosure IP65 compliant (DIN terminal, Common exhaust) Choice of metal or rubber seal for main valve construction

Cylinder Speed Chart

Body Ported	1							F	Jse as a guid Please confiri	le for selection m the actual	on. conditions v	vith SMC Sizi	ng Program.	
Series	Average speed (mm/s)	Series CJ Pressure Load facto Stroke 60	0.5 MPa or 50%		Series CM Pressure Load facto Stroke 30	0.5 MPa or 50%	Bor	e size	Series ME Pressure Load facto Stroke 50	0.5 MPa or 50%				
		ø6	ø10	ø16	ø20	ø25	ø32	ø40	ø40	ø50	ø63	ø80	ø100	
VQZ1121-C6	800 700 600 500 400 300 200										Perpend Horizont	icular, upward al actuation	actuation	SJ
	100 0													SY
VQZ2121-C6	800 700 600 500													SV
VQ22121-C0	400 300 200 100 0													SYJ
NO70404 00	800 700 600 500													SZ VP4
VQZ3121-C6	400 300 200 100 0													S0700
Base Mount	ed		1	1	1				1		1			VQ
	Average	Series CJ			Series CM		Bor	e size	Series ME	8, CA2				VQ4
Series	speed (mm/s)	Pressure Load facto Stroke 60	or 50%		Load facto	Pressure 0.5 MPa Load factor 50% Stroke 300 mm			Pressure 0.5 MPa Load factor 50% Stroke 500 mm					VQ5
	800	ø6	ø10	ø16	ø20	ø25	ø32	ø40	ø40	ø50	Ø63	Ø80 icular, upward	ø100 actuation	VQC
VQZ1151-01	700 600 500										Horizont	al actuation		VQZ
VQ21131-01	400 300 200 100 0													SQ
	800 700 600													VFS
VQZ2151-02	500 400 300 200 100 0													VFR VQ7
VQZ3151-03	0 900 800 700 600 500 400 300 200 100 0													

* It is when the cylinder is extending that is meter-out controlled by speed controller which is directly connected with cylinder, and its needle valve with being fully open.
 * The average velocity of the cylinder is what the stroke is divided by the total stroke time.
 * Load factor: ((Load weight x 9.8)/Theoretical output) x 100%

Conditions

.)

Body	ported	Series CJ2	Series MB, CA2				
	Tube x Length						
VQZ1121-C6	Speed controller		AS2051F-06				
	Silencer	AN120-M5					
	Tube x Length	T0604 x 1m					
VQZ2121-C6	Speed controller	AS3001F-06					
	Silencer	INA-25-46					
	Tube x Length	T1075 x 1m					
VQZ3121-C6	Speed controller		AS4001F-10				
	Silencer	AN101-01					

Base	mounted	Series CJ2	Series CM2	Series MB, CA2				
	Tube x Length		T0604 x 1 m					
VQZ1151-01	Speed controller		AS3001F-06					
	Silencer	AN110-01						
	Tube x Length	T0604 x 1 m T0806 x 1 m						
VQZ2151-02	Speed controller	AS3001F-06 AS3001F-08						
	Silencer		AN200-02					
	Tube x Length	T0604 x 1 m	T1075 x 1 m	T1209 x 1 m				
VQZ3151-03	Speed controller	AS3001F-06	AS4001F-10	AS4001F-12				
	Silencer		AN300-03					



SMC

Series VQZ Model Selection



* Flow characteristics: $4/2 \rightarrow 5/3$ (A/B \rightarrow 910



Manifold

Body Ported -

- P.925

				Piping specific	ations	Applicable		
	Series	Base model	Piping		t size	solenoid	Applicable stations	
CPP PP			direction	1(P), 3·5(R)	4(A), 2(B)	valve		
Preside All Il Harace					C3 (for ø3.2) C4 (for ø4)	VQZ1□20 VQZ1□21	2 to 20	SJ
Cillete Print	VQZ1000	VV5QZ12-□□□	Тор		C6 (for ø6) M5 (M5 thread)		stations	SY
	VQZ2000	VV5QZ22-□□□	Тор	Rc 1/8	C4 (for ø4)	VQZ2□20	2 to 20	SV
	VQZZUUU		100		C6 (for ø6) M5 (M5 thread)	VQZ2□21	stations	SYJ
	VQZ3000	VV5QZ32-□□□	Тор	Rc 1/4	C6 (for ø6) C8 (for ø8)	VQZ3□20	2 to 20	SZ
Serial Transmission — P.936 System	VQ23000		тор		C10 (for ø10) Rc 1/4	VQZ3⊡21	stations	VP4
								S0700
								VQ
								VQ4
								VQ5
								VQC
								VQZ
Base Mounted							– P.954	SQ



			Piping specific	ations	Applicable	Annlinghia	
Series	Base model	Piping	Por	t size	solenoid	Applicable stations	
		direction	1(P), 3·5(R)	4(A), 2(B)	valve	Stations	
VQZ1000	VV5QZ15-□□□	Side	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ1⊡50 VQZ1⊡51	2 to 20 stations	
VQZ2000	VV5QZ25-□□□	Side	Rc 1/4	C4 (for ø4) C6 (for ø6) C8 (for ø8) Rc 1/8	VQZ2⊟50 VQZ2⊟51	2 to 20 stations	
VQZ3000	VV5QZ35-□□□	Side	1(P) port Rc 3/8 3 ⋅ 5(R) port Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3⊟50 VQZ3⊟51	2 to 20 stations	

Serial Transmission -System – P.969





VFS

VFR

VQ7

Series VQZ

Manifold Options



Base Mounted



SMC

Body Ported

Plug Lead Unit

5 Port Solenoid Valve Series VQZ1000/2000/3000 Single Unit (C [Option]



SMC



Specifications

	Туре		Metal seal	Rubber seal			
Fluid			Air, Inert gas				
Max. operating pro	essure (MPa)		0.7 (High pressure type: 1.0)	0.7			
Min. operating	2 position	Single	0.1	0.15			
pressure (MPa)	2 position	Double	VQZ3000, 3 position only	0.1			
,	3 position		0.15	0.2			
Ambient and fluid	temperature	(°C)	_10 to 50 (№	No freezing)			
Max. operating	2 position single, double		20	5			
frequency (Hz)	3 position		10	3			
Manual override			Non-locking push type, Lo	cking type (Tool required)			
Pilot exhaust met	hod		Individual exhaust				
Lubrication			Not required				
Mounting orientat	ion		Single: Free Double, 3 position: Main valve must be horizontal.	Free			
Impact/Vibration r	esistance (m	/s ²) Note 1)	150	/30			
Enclosure*			Dustproof (DIN terminal: IP65 Note 2)				
* Based on IEC60529 Note 1) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-							

energized states every once for each condition. (Value in the initial state) Vibration resistance: No malfunction occurred in one sweep test between 45 and 2000 Hz. Test was performed to axis and right angle directions of the main valve and armature when pilot signal is ON and OFF. (Value in the initial state) Note 2) When IP65 compliant DIN terminals are selected: VQZ²₃□21□-□Y□□W1-□-□

Solenoid Specifications

Electrical entry			Grommet (G) L-type plug connector (L)	M-type plug connector (M) DIN terminal (Y)				
			G, L, M	Y				
Coil rated voltage		DC	24, 12					
(V)		AC 50/60 Hz	100, 110,	200, 220*				
Allowable voltage	fluctu	uation	±10% of ra	ted voltage				
Power	DC	Standard	0.35 [(With light: 0.4 (DIN	I terminal with light: 0.45)]				
consumption (W)	DC	High speed response, high pressure	0.9 [(With light: 0.95 (DIN terminal with light: 1.0					
		100V	0.78 (With light: 0.81)	0.78 (With light: 0.87)				
	AC	110V	0.86 (With light: 0.89)	0.86 (With light: 0.87)				
Apparent power		[115V]	[0.94 (With light: 0.97)]	[0.94 (With light: 1.07)]				
(VA)*	AC	200V	1.18 (With light: 1.22)	1.15 (With light: 1.30)				
		220V	1.30 (With light: 1.34)	1.27 (With light: 1.46)				
		[230V]	[1.42 (With light: 1.46)]	[1.39 (With light: 1.60)]				
Surge voltage sup	press	sor	Var	istor				
Indicator light	AC with DIN terminal)							
 In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC. ★ For 115 VAC and 230 VAC, the allowable voltage is -15% to +5% of rated voltage. 								

Flow Characteristics

Options

Made to Order

Symbol

X30

X90 X113

High speed response type

High pressure type (Metal seal type only) External pilot type (Except VQZ1000)* * For details on external pilot type, refer to page 933.

Made to Order

(For details, refer to page 975.)

Pilot valve common exhaust

Main valve fluoro-rubber All fluoro-rubber

Description

						F	low cha	racteristics			Res	oonse tin	ne (ms) [⊾]	Note 1)	Note 2)
Series	C	Configuration	Mode	əl	1→4	/2 (P→A	/B)	4/2→5/3	(A/B→E	A/EB)	Standard:	High speed	High pressure:		Mass
		0			C [dm3/(s•bar)]	b	Cv	C [dm3/(s•bar)]	b	Cv	0.35 W	0.9 W	0.9 W	AC	(g)
		0. 1	Metal seal	VQZ1120	0.54	0.20	0.13	0.54	0.26	0.13	17 or less	12 or less	15 or less	29 or less	45
	2	Single	Rubber seal	VQZ1121	0.90	0.40	0.26	0.71	0.40	0.19	17 or less	12 or less	-	34 or less	45
	position	Daubla	Metal seal	VQZ1220	0.54	0.20	0.13	0.54	0.26	0.13	10 or less	10 or less	13 or less	13 or less	62
		Double	Rubber seal	VQZ1221	0.90	0.40	0.26	0.71	0.40	0.19	10 or less	10 or less	_	13 or less	02
VQZ1000		Closed center	Metal seal	VQZ1320	0.55	0.29	0.13	0.50	0.25	0.08	25 or less	20 or less	26 or less	40 or less	
	3	Closed certier	Rubber seal	VQZ1321	0.87	0.38	0.23	0.68	0.39	0.18	30 or less	25 or less	_	47 or less]
t	position	Exhaust center	Metal seal	VQZ1420	0.55	0.28	0.13	0.54	0.26	0.13	25 or less	20 or less	26 or less	40 or less	65
			Rubber seal	VQZ1421	0.87	0.38	0.23	0.71	0.40	0.19	30 or less	25 or less	_	47 or less	
		Pressure center	Rubber seal	VQZ1521	0.91	0.41	0.26	0.68	0.39	0.18	30 or less	25 or less	—	47 or less]
		Single	Metal seal	VQZ2120	1.2	0.21	0.30	1.4	0.20	0.32	18 or less	14 or less	18 or less	34 or less	65
	2	- 0	Rubber seal	VQZ2121	1.7	0.39	0.45	1.6	0.35	0.44	20 or less	15 or less	_	36 or less	60
	position	Double	Metal seal	VQZ2220	1.2	0.21	0.30	1.4	0.20	0.32	10 or less	10 or less	13 or less	13 or less	84
			Rubber seal	VQZ2221	1.7	0.39	0.45	1.6	0.35	0.44	12 or less	12 or less	-	15 or less	04
VQZ2000		Closed center	Metal seal	VQZ2320	1.1	0.21	0.26	1.1	0.24	0.26	28 or less	23 or less	30 or less	44 or less	
VQLLUUU		Closed certier	Rubber seal	VQZ2321	1.4	0.33	0.35	1.4	0.37	0.36	30 or less	25 or less	-	47 or less	
	3	Exhaust center	Metal seal	VQZ2420	1.1	0.23	0.28	1.4	0.20	0.32	28 or less	23 or less	30 or less	44 or less	91
	position		Rubber seal	VQZ2421	1.4	0.33	0.35	1.6	0.35	0.44	30 or less	25 or less	_	47 or less	91
		Pressure center	Metal seal	VQZ2520	1.3	0.28	0.34	1.2	0.27	0.30	28 or less	23 or less	30 or less	44 or less	
		Flessule celliel	Rubber seal	VQZ2521	1.7	0.34	0.44	1.4	0.37	0.36	30 or less	25 or less	-	47 or less	
		Cinala	Metal seal	VQZ3120	2.4	0.23	0.56	2.4	0.19	0.54	21 or less	17 or less	22 or less	34 or less	108
	2	Single	Rubber seal	VQZ3121	3.1	0.34	0.79	3.2	0.38	0.81	33 or less	25 or less	_	57 or less	108
	position	Double	Metal seal	VQZ3220	2.4	0.23	0.56	2.4	0.19	0.54	10 or less	10 or less	13 or less	13 or less	125
		Double	Rubber seal	VQZ3221	3.1	0.34	0.79	3.2	0.38	0.81	15 or less	15 or less	_	20 or less	125
VQZ3000		Closed center	Metal seal	VQZ3320	2.3	0.19	0.54	2.1	0.21	0.54	33 or less	25 or less	33 or less	53 or less	
	az3000	Closed certiel	Rubber seal	VQZ3321	2.7	0.30	0.66	2.4	0.33	0.62	35 or less	30 or less	-	59 or less	
	3	Exhaust center	Metal seal	VQZ3420	2.3	0.19	0.54	2.4	0.19	0.54	33 or less	25 or less	33 or less	53 or less	136
	position	Lanausi center	Rubber seal	VQZ3421	2.7	0.30	0.66	3.2	0.38	0.81	35 or less	30 or less	_	59 or less	s 136
	, i i i i i i i i i i i i i i i i i i i	Pressure center	Metal seal	VQZ3520	2.5	0.25	0.60	2.1	0.18	0.47	33 or less	25 or less	33 or less	53 or less	
		Fiessure Ceriler	Rubber seal	VQZ3521	3.2	0.38	0.82	2.4	0.33	0.62	35 or less	30 or less	-	59 or less	

Note 1) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa; with light/surge voltage suppressor: clean air)

Response time values will change depending on pressure and air quality. Note 2) Weight for threaded connection



Construction: VQZ1000/2000/3000



Component Parts

No.	Description	Material	Note
1	Body	Aluminum die-casted	
0	Spool, Sleeve	Stainless steel	Metal seal
2	Spool valve	Aluminum/HNBR	Rubber seal
3	Piston	Resin	
4	Pilot valve assembly	—	

Note) For "How to Order Pilot Valve Assembly", refer to page 934.

Dimensions: VQZ1000



Dimensions: VQZ1000

2 Position Double

Grommet (G): VQZ122 ⁰/₁-□G□1-C3, C4, C6



SMC

Unless otherwise indicated, dimensions are the same as Grommet (G).

Unless otherwise indicated, dimensions are the same as Grommet (G). []: AC

Dimensions: VQZ1000

3 Position Closed Center/Exhaust Center/Pressure Center (Except Metal seal type)

Grommet (G): VQZ1 $\frac{3}{4}$ 2 $\frac{9}{1}$ - \Box G \Box 1-C3, C4, C6



SMC



Unless otherwise indicated, dimensions are the same as Grommet (G).
[]: AC



Unless otherwise indicated, dimensions are the same as Grommet (G). []: AC

Dimensions: VQZ2000



Dimensions: VQZ2000

2 Position Double



Dimensions: VQZ2000



Dimensions: VQZ3000



Dimensions: VQZ3000



SMC

M-type plug connector (M): VQZ322⁰₁ (R)-□M□1-C6, C8, C10



Unless otherwise indicated, dimensions are the same as Grommet (G). [$\$]: AC



Unless otherwise indicated, dimensions are the same as Grommet (G).

Dimensions: VQZ3000



SMC

L-type plug connector (L): VQZ3 $\frac{3}{5}$ 2 $\frac{9}{1}$ (R)- \Box L \Box 1-C6, C8, C10



M-type plug connector (M): VQZ3 $\frac{3}{4}$ 2 $\frac{0}{1}$ (R)- \Box M \Box 1-C6, C8, C10



Unless otherwise indicated, dimensions are the same as Grommet (G).]: AC [

924



Unless otherwise indicated, dimensions are the same as Grommet (G).

167.9

Body Ported

Plug Lead Unit

5 Port Solenoid Valve Series VQZ1000/2000/3000 Manifold Connector Kit (C [Option]



Manifold Specifications



		Pip	ing spec	ifications	Applicable	Annilisable	Manifold
Series	Base model	Piping	F	Port size	solenoid	Applicable stations	base
		direction	1(P), 3/5(R)	4(A), 2(B)	valve		mass (g)
VQZ1000	VV5QZ12-□□□	Тор	Rc 1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ1⊡20 VQZ1⊡21	2 to 20 stations	2 stations: 64 Addition per station: 18
VQZ2000	VV5QZ22-□□□	Тор	Rc 1/8	C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ2⊡20 VQZ2⊡21	2 to 20 stations	2 stations: 86 Addition per station: 26
VQZ3000	VV5QZ32-□□□	Тор	Rc 1/4	C6 (for ø6) C8 (for ø8) C10 (for ø10) Rc 1/4	VQZ3⊡20 VQZ3⊡21	2 to 20 stations	2 stations: 181 Addition per station: 53

How to Order Manifold Assembly (Example)



Dimensions: VQZ1000

VV5QZ12- Stations C





Dimensions: VQZ2000



L4

19.5

20.5



16.5

15.5

17.5

18.5

16.5

15.5



Dimensions: VQZ3000

L5

SMC

Manifold Options

Blanking plate assembly VVQZ1000-10A-2 (for VQZ1000) VVQZ2000-10A-2 (for VQZ2000) VVQZ3000-10A-2 (for VQZ3000)

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.



DIN rail AXT100-DR-

* As for
, enter the number from the DIN rail dimensions table. For L dimension, refer to the dimensions of each kit.

Each manifold can be mounted on a DIN rail.

Insert "D" at the end of the manifold part number. The DIN rail is approximately 30 mm longer than the length of manifold.

ι.	ni	m	er	ici	
ь.	וט		eı	15	U

L Dime	L Dimension L = 12.5n + 10.5														10.5					
No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5

đ

 $\Rightarrow \Phi \Phi \Phi \Phi \Phi \Phi \Phi \Phi$

Blanking plug KQ2P-23 **KQ2P-04 KQ2P-06 KQ2P-08** KQ2P-10





Dimensions

Applicable fitting size ød	Model	Α	L	D
3.2	KQ2P-23	16	31.5	3.2
4	KQ2P-04	16	32	6
6	KQ2P-06	18	35	8
8	KQ2P-08	20.5	39	10
10	KQ2P-10	22	43	12

7.5

Silencer (for manifold EXH port)

Silencer is installed in the manifold EXH port.





Dimensions											
Model	Silencer part no.										
VQZ1000	AN110-01										
VQZ2000	AN110-01										
VQZ3000	AN200-02										

Port plug VVQZ100-CP (for VQZ1000/2000) VVQZ2000-CP (for VQZ3000)

Used to block a cylinder port when changing 5 port valves into 3 port valves, etc.



Manifold Options



Manifold Options

Perfect block (Separated): For VQZ2000/3000 VQ2000-FPG-

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the perfect block with a built-in pilot type perfect valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in § the middle or maintain its position for a long time. The combination of a 2 position single or double solenoid with a perfect block will prevent the cylinder from "dropping" at stroke end when residual supply pressure is released.

Specifications

FB F

<u>_</u> -

58

(59.5)

0.8 MPa
0.15 MPa
–5 to 50°C
3.0 dm ³ /(s⋅bar)
180 c.p.m

<Check valve operating principle>

block



<Ordering Example>

VVQ2000-FPG-06 ···· 6 stations of manifold * VQ2000-FPG-C6C6-D, 3 sets Perfect

* VQ2000-FPG-C8C8-D, 3 sets block

932

01

02

C6

C8



If exhaust side of perfect block is narrowed down too much, intermediate stopping accuracy will be decreased.

pressure will be within two times that of the supply pressure.



External Pilot Specification (Except VQZ1000)

The external pilot specification is used when the operating pressure is below the minimum operating pressure 0.1 to 0.2 MPa or when valve is used for a vacuum application. Order a valve by adding the external pilot specification [R] to the part number.



Series VQZ Body Ported **Replacement Parts**

One-touch Fitting Assembly (for Cylinder port)

Fitting size Model	Сз	C4	C6	C8	C10
VQZ1000/2000	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	—	—
VQZ3000	—	—	VVQ1000-51A-C6	VVQ1000-51A-C8	VVQ1000-51A-C10

Note) Purchasing order is available in units of 10 pieces.



How to Order

Include the connector assembly part number together with the part number for the plug connector's solenoid valve without connector.

Example) In case of 2000 mm of lead wire

DC

AC

/ VO700000000

VQZ1120-5LO1-M5 SY100-30-4A-20	VQZ1120-1LO1-M5 SY100-30-1A-20	<din (applicable="" 3000)="" terminal="" the="" to="" type="" vqz2000=""></din>	
<gasket and="" so<="" th=""><th></th><th>V115 5 Y - X110</th><th></th></gasket>		V115 5 Y - X110	
	Part no.	Function •	
VQZ1000	VQZ1000-GS-2	Symbol Specifications DC AC	
VQZ2000	VQZ2000-GS-2	Nil Standard	
VQZ3000	VQZ3000-GS-2	B Note) High speed response type	
Each unit ha	number consists of 10 un as one gasket and two chasing order is availabl pieces		
	3 3	Coil voltage • Electrical	entrv
	8	1 100 VAC (50/60 Hz) Electrical entry	Light/sur voltage suppress
		3 110 VAC [115 VAC] (50/60 Hz) Y DIN terminal	None
		4 220 VAC [230 VAC] (50/60 Hz) YO DIN terminal without connector	
<u> </u>	ð,	5 24 VDC YZ DIN terminal with light/surge voltage suppressor 6 12 VDC vc DIN terminal with surge voltage suppressor	Yes
le l	Ď	YS (DC specification)	Yes (Wi
	69	YOS DIN terminal with surge voltage suppressor, without connector (DC specification)	indicato light)
<bracket assen<="" td=""><td>nbly></td><td>Note) For AC voltage valves there is no "S" option. It</td><td>t is</td></bracket>	nbly>	Note) For AC voltage valves there is no "S" option. It	t is
	Part no.	Tightening torque (N•m) Note) already built-in to the rectifier circuit.	
VQZ1000 Metal seal	VQZ1000V-FB-M	0.2 to 0.26	
Rubber sea	al VQZ1000V-FB-R		
VQZ2000	VQZ2000-FB	0.25 to 0.35 Caution	
VQZ3000	VQZ3000-FB	0.25 to 0.35	embly,

SMC

plate and bracket at the tightening torque shown in the table, using the screws attached to the bracket assembly. Place the spring inside the end plate in its original position so that it does not get lost.

use caution because it is not possible to convert to a V115 (DIN terminal) from a V111 (Grommet, L-type, M-type), or vice versa.

EX510 Gateway System Serial Transmission System Series VQZ1000/2000/3000 Body Ported Manifold

CE [Option]



How to Order Valve Manifold Assembly (Example)



SI Unit Part No.

Symbol	SI unit spec.	SI unit part no.
Nil	NPN output (+COM.)	EX510-S001
N	PNP output (-COM.)	EX510-S101

For details of "Gateway System Serial Transmission System, Series EX510", refer to pages 1696 to 1724.

EX510 Gateway System Serial Transmission System Series VQZ1000/2000/3000

How to Order Valve



(For details, refer to page 975.)

	· · · · · · · · · · · · · · · · · · ·	'
Symbol	Description	
X30	Pilot valve common exhaust	
X90	Main valve fluoro-rubber	
X113	All fluoro-rubber	

Dimensions: VQZ1000-SA: EX510 Gateway System Serial Transmission System



Dimensions Max														Max. 16	stations
L n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	123	123	123	123	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248
L2	112.5	112.5	112.5	112.5	112.5	125	137.5	150	162.5	175	187.5	200	212.5	225	237.5
L3	88	88	88	88	88	100	112	124	136	148	160	172	184	196	208
L4	17.5	17.5	17.5	17.5	17.5	18	18.5	18.5	19	19	19	19.5	19.5	20	20
L5	80	80	80	80	80	92	104	116	128	140	152	164	176	188	200

Note) The L dimension of 2 to 6 stations is the same. Valves are numbered from the D side according up to the number of stations.

_ .

Dimensions: VQZ2000-SA: EX510 Gateway System Serial Transmission System



The dashed lines indicate the DIN rail mounting [-D].

Unless otherwise indicated, dimensions are the same as L-type plug connector (L).
[]: AC

Dimens	Dimensions														stations
L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	135.5	135.5	135.5	135.5	160.5	173	185.5	210.5	223	248	260.5	273	298	310.5	323
L2	125	125	125	125	150	162.5	175	200	212.5	237.5	250	262.5	287.5	300	312.5
L3	104	104	104	104	121	138	155	172	189	206	223	240	257	274	291
L4	16	16	16	16	20	17.5	15.5	19.5	17	21	19	16.5	20.5	18.5	16
L5	94	94	94	94	111	128	145	162	179	196	213	230	247	264	281

Note) The L dimension of 2 to 6 stations is the same. Valves are numbered from the D side according up to the number of stations.

Dimensions: VQZ3000-SA: EX510 Gateway System Serial Transmission System



Dimens	sions													Max. 16	stations
L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	123	123	148	173	185.5	210.5	223	248	273	285.5	310.5	323	348	373	385.5
L2	112.5	112.5	137.5	162.5	175	200	212.5	237.5	262.5	275	300	312.5	337.5	362.5	375
L3	92	92	112	132	152	172	192	212	232	252	272	292	312	332	352
L4	15.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17
L5	70	70	90	110	130	150	170	190	210	230	250	170	290	310	330

Note) The L dimension of 2 to 6 stations is the same. Valves are numbered from the D side according up to the number of stations.

Manifold Options

Connector assembly



Double solenoid (SY3000-37-81A-□-□)



Connector Assembly Part No. (for a manifold with 8 stations or less with an unspecified layout) Bar Stock Type

Model	Part no.	Connector mounting position				
	SY3000-37-81A-3-N	Single: for 1 to 4 stations				
VV5QZ12	SY3000-37-81A-3-6	Double/3 position: for 1 to 4 stations				
VV5QZ12	SY3000-37-81A-2-N	Single: for 5 to 8 stations				
	SY3000-37-81A-3-6	Double/3 position: for 5 to 8 stations				
VV5QZ22	SY3000-37-81A-3-N	Single: for 1 to 8 stations				
VV5QZZZ	SY3000-37-81A-3-6	Double/3 position: for 1 to 8 stations				
	SY3000-37-81A-3-N	Single: for 1 to 4 stations				
VV5QZ32	SY3000-37-81A-3-6	Double/3 position: for 1 to 4 stations				
VV5QZ32	SY3000-37-81A-4-N	Single: for 5 to 8 stations				
	SY3000-37-81A-4-7	Double/3 position: for 5 to 8 stations				

Note) There are no part nos. on the connectors of connector assemblies.

Connector assembly

SY3000-37-80A-



Housing (1 set: 8 pieces) SY3000-44-3A



(+)

(+)

91
SV
SYJ
SZ
VP4
S0700
VQ
VQ4
VQ5
VQC
VQZ
SQ
VFS
VFR
VQ7

SJ

٩٧

Connector Assembly Part No. (for a manifold with a specified layout)

Model	Assembly part no.	Connect	or mounting position	
	SY3000-37-80A-3	A side	For 1 to 8 stations	
VV5QZ12	SY3000-37-80A-6	FOI T IO O SIALIONS		
VV5QZ1Z	SY3000-37-80A-4	A side	For 9 to 16 stations	
	SY3000-37-80A-7	B side	FOI 9 to 16 stations	
	SY3000-37-80A-3	A side	For 1 to 8 stations	
VV5QZ22	SY3000-37-80A-6			
VVJQZZZ	SY3000-37-80A-7	A side	For 9 to 16 stations	
	SY3000-37-80A-9	B side	FOI 9 to 16 stations	
	SY3000-37-80A-4	A side	For 1 to 8 stations	
VV5QZ32	SY3000-37-80A-7	B side	FOLT IO O SIAIIONS	
VV5QZ3Z	SY3000-37-80A-8	A side	For 9 to 16 stations	
	SY3000-37-80A-11	FOI 9 IO 16 Stations		

Note 1) Since these connector assemblies are used when adding stations or for maintenance, there are no part nos. on them.

Note 2) After inserting the connector assembly into the housing, slightly pull the lead wire to make sure it does not pull out. Do not reuse the lead wire once it has been inserted.

Note 3) Please note that the wires are longer than the actual wiring distance.



Base Mounted

Plug Lead Unit

5 Port Solenoid Valve Series VQZ1000/2000/3000 Single Unit (C [Option]



duty.



Note) For sub-plate part no., refer to page 967.

Base Mounted Series VQZ1000/2000/3000



Specifications

Туре			Metal seal	Rubber seal				
Fluid	••		Air, Inert gas					
Max. operating pre	essure (MPa)		0.7 (High pressure type: 1.0)	0.7				
Min energing	2 position	Single	0.1	0.15				
Min. operating pressure (MPa)	2 position	Double	VQZ3000, 3 position only	0.1				
pressure (MPa)	3 position		0.15	0.2				
Ambient and fluid			-10 to 50 (N	lo freezing)				
Max. operating		single, double	20	5				
frequency (Hz)	3 position		10	3				
Manual override			Non-locking push type, Locking type (Tool required)					
Pilot exhaust meth	nod		Individual exhaust					
Lubrication			Not re	quired				
Mounting orientation			Single: Free Double, 3 position: Main valve must be horizontal.	Free				
Impact/Vibration r	esistance (m	/s ²) Note 1)	150	/30				
Enclosure*			Dustproof (DIN terminal: IP65 Note 2)					
Vibratio	t resistance: N e n resistance: N v v	and at the right and energized states e lo malfunction occ performed to axis a when pilot signal is	curred when it is tested with a dr gles to the main valve and armar very once for each condition. (V. curred in one sweep test betwee and right angle directions of the s ON and OFF. (Value in the initi re selected: VOZ_2° $=51{}$	ture in both energized and de alue in the initial state) n 45 and 2000 Hz. Test was main valve and armature al state)				

Solenoid Specifications

Electrical entry		Grommet (G)	M-type plug connector (M)					
		L-type plug connector (L)	DIN terminal (Y)					
			G, L, M	Y				
Coil rated voltage		DC	24,	, 12				
(V)		AC 50/60 Hz	100, 110,	200, 220*				
Allowable voltage	fluctu	uation	±10% of ra	ited voltage				
Power	DC	Standard	0.35 [(With light: 0.4 (DIN terminal with light: 0.45)]					
consumption (W)	DC	High speed response, high pressure	0.9 [(With light: 0.95 (DIN terminal with light: 1.0)					
	AC	100V	0.78 (With light: 0.81)	0.78 (With light: 0.87)				
		110V	0.86 (With light: 0.89)	0.86 (With light: 0.87)				
Apparent power		[115V]	[0.94 (With light: 0.97)]	[0.94 (With light: 1.07)]				
(VA)*		200V	1.18 (With light: 1.22)	1.15 (With light: 1.30)				
		220V	1.30 (With light: 1.34)	1.27 (With light: 1.46)				
		[230V]	[1.42 (With light: 1.46)]	[1.39 (With light: 1.60)]				
Surge voltage sup	press	sor	Varistor					
Indicator light			LED (Neon light when AC with DIN terminal)					
* In common between 110 VAC and 115 VAC, and between 220 VAC and 230 VAC. * For 115 VAC and 230 VAC, the allowable voltage is -15% to $+5\%$ of rated voltage.								

Options

High speed response type
High pressure type (Metal seal type only)

External pilot type*

* For details on external pilot type, refer to page 966.

Made to	Made to Order
Order	(For details, refer to page 975.)
Symbol	Description

Symbol	Description						
X30	Pilot valve common exhaust						
X90	Main valve fluoro-rubber						
X113	All fluoro-rubber						

Flow Characteristics

					Flow characteristics						Response time (ms) Note 1)				Note 2)
Series	Configuration		Model			$1 \rightarrow 4/2 (P \rightarrow A/B)$ $4/2 \rightarrow 5/3 (A/B \rightarrow EA/EB)$				EA/EB)	Standard: Hig	High speed response:	High pressure:	AC	Mass
					C [dm ³ /(s•bar)] b		Cv	C [dm ³ /(s•bar)]	b Cv		0.35 W	0.9 W	0.9 W	AC	(g)
		Cinala	Metal seal	VQZ1150	0.70	0.21	0.17	0.70	0.21	0.17	17 or less	12 or less	15 or less	29 or less	40
	2	Single	Rubber seal	VQZ1151	1.2	0.35	0.30	1.3	0.24	0.32	17 or less	12 or less	—	34 or less	40
	position	Double	Metal seal	VQZ1250	0.70	0.21	0.17	0.70	0.21	0.17	10 or less	10 or less	13 or less	13 or less	57
		Double	Rubber seal	VQZ1251	1.2	0.35	0.30	1.3	0.24	0.32	10 or less	10 or less	-	13 or less	5
VQZ1000		Closed center	Metal seal	VQZ1350	0.56	0.20	0.13	0.57	0.22	0.14	25 or less	20 or less	26 or less	40 or less	
	3	Closed certier	Rubber seal	VQZ1351	1.1	0.33	0.27	1.0	0.38	0.27	30 or less	25 or less	—	47 or less	
	position	Exhaust center	Metal seal	VQZ1450	0.56	0.20	0.13	0.70	0.21	0.17	25 or less	20 or less	26 or less	40 or less	60
		Exhaust center	Rubber seal	VQZ1451	1.1	0.33	0.27	1.3	0.24	0.32	30 or less	25 or less	—	47 or less	
		Pressure center	Rubber seal	VQZ1551	1.4	0.20	0.34	1.0	0.38	0.27	30 or less	25 or less	—	47 or less	
		Single	Metal seal	VQZ2150	1.6	0.13	0.36	1.9	0.16	0.40	18 or less	14 or less	18 or less	34 or less	61
	2	Single	Rubber seal	VQZ2151	2.0	0.35	0.51	2.3	0.29	0.53	20 or less	15 or less	—	36 or less	
	position	Double	Metal seal	VQZ2250	1.6	0.13	0.36	1.9	0.16	0.40	10 or less	10 or less	13 or less	13 or less	
			Rubber seal	VQZ2251	2.0	0.35	0.51	2.3	0.29	0.53	12 or less	12 or less	—	15 or less	
VQZ2000	3 position	Closed center	Metal seal	VQZ2350	1.5	0.16	0.35	1.3	0.26	0.32	28 or less	23 or less	30 or less	44 or less	87 8
VQZ2000			Rubber seal	VQZ2351	1.7	0.27	0.39	1.7	0.28	0.39	30 or less	25 or less	—	47 or less	
		Exhaust center	Metal seal	VQZ2450	1.5	0.16	0.35	1.9	0.16	0.40	28 or less	23 or less	30 or less	44 or less	
			Rubber seal	VQZ2451	1.7	0.27	0.39	2.3	0.29	0.53	30 or less	25 or less	—	47 or less	
		Pressure center	Metal seal	VQZ2550	1.8	0.13	0.39	1.5	0.26	0.36	28 or less	23 or less	30 or less	44 or less	
			Rubber seal	VQZ2551	2.0	0.35	0.50	1.7	0.28	0.39	30 or less	25 or less	_	47 or less	
		Single	Metal seal	VQZ3150	2.6	0.12	0.60	3.0	0.15	0.74	21 or less	17 or less	22 or less	34 or less	- 93
	2	Single	Rubber seal	VQZ3151	3.9	0.29	1.0	4.6	0.26	1.2	33 or less	25 or less	—	57 or less	93
	position	Double	Metal seal	VQZ3250	2.6	0.12	0.60	3.0	0.15	0.74	10 or less	10 or less	13 or less	13 or less	110
		Double	Rubber seal	VQZ3251	3.9	0.29	1.0	4.6	0.26	1.2	15 or less	15 or less	—	20 or less	
VQZ3000		Closed center	Metal seal	VQZ3350	2.4	0.12	0.58	2.8	0.16	0.65	33 or less	25 or less	33 or less	53 or less	s s 121
VG25000			Rubber seal	VQZ3351	3.1	0.33	0.82	3.6	0.35	0.97	35 or less	30 or less	—	59 or less	
	3	Exhaust center	Metal seal	VQZ3450	2.4	0.12	0.58	3.0	0.15	0.74	33 or less	25 or less	33 or less	53 or less	
	position		Rubber seal	VQZ3451	3.9	0.33	0.82	4.6	0.26	1.2	35 or less	30 or less	—	59 or less	
		Drocouro contor	Metal seal	VQZ3550	3.0	0.12	0.69	2.9	0.16	0.65	33 or less	25 or less	33 or less	53 or less	
		Pressure center	Rubber seal	VQZ3551	4.4	0.27	1.1	3.6	0.35	0.97	35 or less	30 or less	_	59 or less	1

Note 1) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa; with light/surge voltage suppressor: clean air)

)) Response time values will change depending on pressure and air quality. The values at the time of ON are given for double types.

Note 2) Weight without sub-plate
Construction: VQZ1000/2000/3000



Component Parts

No.	Description	Material	Note
1	Body	Aluminum die-casted	
	Spool, Sleeve	Stainless steel	Metal seal
2	Spool valve	Aluminum/HNBR	Rubber seal
3	Piston	Resin	
4	Pilot valve assembly	—	

Note) For "How to Order Pilot Valve Assembly", refer to page 967.



Dimensions: VQZ1000

]: AC

2 Position Single/3 Port for Mixture Mounting



SMC

[]: AC

Dimensions: VQZ1000

2 Position Double

Grommet (G): VQZ125 ⁰₁(R)-□G□1-01



SMC

L-type plug connector (L): VQZ125 ⁰₁(R)-□L□1-01



Unless otherwise indicated, dimensions are the same as Grommet (G).

M-type plug connector (M): VQZ125⁰/₁ (R)-□M□1-01



Unless otherwise indicated, dimensions are the same as Grommet (G). [$_{]}$: AC

Dimensions: VQZ1000

3 Position Closed Center/Exhaust Center/Pressure Center (Except metal seal type)

Grommet (G): VQZ1 ³/₅ 5 ⁰/₁ (R)-□G□1-01



L-type plug connector (L): VQZ1 $\frac{3}{5}$ 5 $\frac{1}{1}$ (R)- \Box L \Box 1-01



M-type plug connector (M): VQZ1 $\frac{3}{5}$ 5 $\frac{9}{1}$ (R)- \Box M \Box 1-01



Unless otherwise indicated, dimensions are the same as Grommet (G). []: AC



Dimensions: VQZ2000





Unless otherwise indicated, dimensions are the same as Grommet (G).

M-type plug connector (M): VQZ2 $\frac{1}{8}$ 5 $\frac{1}{9}$ (R)- \Box M \Box 1- $\frac{01}{02}$





SMC

Dimensions: VQZ2000



SMC

Dimensions: VQZ2000



SMC

L-type plug connector (L): VQZ2 $\frac{3}{5}$ 5 $\frac{5}{1}$ (R)- \Box L \Box 1- $\frac{01}{02}$



M-type plug connector (M): VQZ2 $\frac{3}{5}$ 5 $\frac{1}{1}$ (R)- \Box M \Box 1 $\frac{01}{02}$



DIN terminal (Y): VQZ2 ³/₅ 5 ⁰/₁ (R)-□Y□1-⁰¹₀₂



Unless otherwise indicated, dimensions are the same as Grommet (G).

Dimensions: VQZ3000



Dimensions: VQZ3000



SMC

Unless otherwise indicated, dimensions are the same as Grommet (G).

M-type plug connector (M): VQZ325⁰/₁ (R)-□M□1-⁰²/₀₃





Unless otherwise indicated, dimensions are the same as Grommet (G).

Dimensions: VQZ3000



Base Mounted

Plug Lead Unit

5 Port Solenoid Valve Series VQZ1000/2000/3000 Manifold Connector Kit (c [Option]



Manifold Specifications

			P	iping speci	fications	Applicable		Note) Manifold	
1133	Series	Base model	Piping	Port size		solenoid	Applicable stations	base	
			direction	1(P), 3/5(R)	4(A), 2(B)	valve	stations	mass (g)	
	VQZ1000	VV5QZ15-□□□	Side	Rc1/8	C3 (for ø3.2) C4 (for ø4) C6 (for ø6) M5 (M5 thread)	VQZ1⊡50 VQZ1⊡51	2 to 20 stations	2 stations: 105 Addition per station: 27	
1 8880°					C4 (for ø4)	VQZ2□50	2 to 20 stations	2 stations:	SJ
A DE CONTRACTOR	VQZ2000	VV5QZ25- □□□	Side	Rc1/4	C6 (for ø6) C8 (for ø8) Rc 1/8	VQZ2051		193 Addition per station: 54	SY
				1(P) port Rc 3/8	C6 (for ø6) C8 (for ø8)	VQZ3□50	2 to 20	2 stations: 398	SV
	VQZ3000	VV5QZ35-□□□	Side	3/5(R) port Rc 1/4		VQZ3D51	stations	Addition per station: 102	SYJ
) Weight without sub-pla	ate.						SZ
									VP4
How to Order Manifold Assemb	oly (Exa	ample)							S0700
	2 \	- /							VQ
Example									



VQ4

VQ5

VQC

VQZ

SQ

VFS

VFR

VQ7

Dimensions: VQZ1000



49

18.5

59.5

19.5

51.5

70

62

20.5

80.5

72.5

15

91

16

83

101.5

17

93.5

112

104

18

38.5

17.5

30.5

L4

L5

956



133

125

20

143.5

21

135.5

154

16

146

164.5

17

156.5

175

18

167

185.5

19

177.5

196

20

188

206.5

21

198.5

217

209

15.5

227.5

219.5

16.5

122.5

19

114.5



Dimensions: VQZ2000



Dimensions: VQZ3000



Manifold Options



Port plug VVQZ1000-CP (for VQZ1000) VVQZ2000-CP (for VQZ2000) VVQZ3000-CP (for VQZ3000)

Used to block a cylinder port when changing 5 port valves into 3 port valves, etc.



Manifold Options

Name plate [-N] (Applicable to VQZ2000/3000) VVQZ2000-N5- Stations (for VQZ2000) VVQZ3000-N5-Stations (for VQZ3000)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc. Insert it into the groove on the side of the end plate and bend it as shown in the figure.

- To order a manifold with nameplate already attached, insert "N" at the end of the manifold number.
- * 4 clips are attached for name plate mounting.

DIN rail AXT100-DR-

* As for □, enter the number from the DIN rail dimensions table. For L dimension, refer to the dimensions of each kit.

Each manifold can be mounted on a DIN rail. Order it by indicating an option symbol for DIN rail mounting, -D.

The DIN rail is approximately 30 mm longer than the length of manifold.

1	
Ĩ,	800e





L Dimer	L Dimension L = 12.5n + 10.5																			
No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5

Blanking plug **KQ2P-23 KQ2P-04 KQ2P-06 KQ2P-08** KQ2P-10





Dimensions (mr							
Applicable fitting size ød	Model	Α	L	D			
3.2	KQ2P-23	16	31.5	3.2			
4	KQ2P-04	16	32	6			
6	KQ2P-06	18	35	8			
8	KQ2P-08	20.5	39	10			
10	KQ2P-10	22	43	12			

Silencer (for manifold EXH port)

Silencer is installed in the manifold EXH port.





Model	Silencer part no.
VQZ1000	AN110-01
VQZ2000	AN200-02
VQZ3000	AN200-02

<Check valve operating principle>

Cylinder side pressure

(P₂

SUP side

pressure (P1)

SJ

SY

Manifold Options

Perfect block (Separated): For VQZ1000

VQ1000-FPG-

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the perfect block with a built-in pilot type perfect valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time. The combination of a 2 position single or double solenoid with a perfect block will prevent the cylinder from "dropping" at stroke end when residual supply pressure is released.

Specifications

Maximum operating pressure	0.8 MPa
Minimum operating pressure	0.15 MPa
Ambient and fluid temperature	–5 to 50°C
Flow characteristics: C	0.60 dm ³ /(s·bar)
Max. operating frequency	180 c.p.m



Manifold Options

Perfect block (Separated): For VQZ2000/3000 VQ2000-FPG-

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the perfect block with a built-in pilot type perfect valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time. The combination of a 2 position single or double solenoid with a perfect block will prevent the cylinder from "dropping" at stroke end when residual supply pressure is released.

Specifications

Ħ₹

<u>_</u> ----

58

(59

20.5

0.8 MPa
0.15 MPa
–5 to 50°C
3.0 dm ³ /(s·bar)
180 c.p.m



<Check valve operating principle>



pressure will be within two times that of the supply pressure. If exhaust side of perfect block is narrowed down too much, intermediate stopping accuracy • will be decreased

* VQ2000-FPG-C8C8-D, 3 sets

block



Compact Body Type with Restrictor: For VQZ2000



Dimensions: VQZ2000 (Compact Body Type: Single Unit)





SMC



Unless otherwise indicated, dimensions are the same as Grommet (G).



Unless otherwise indicated, dimensions are the same as Grommet (G).



Dimensions: VQZ2000 (Compact Body Type: Manifold)

SMC



External Pilot Specification

The external pilot specification is used when the operating pressure is below the minimum operating pressure 0.1 to 0.2 MPa or when valve is used for a vacuum application. Order a valve by adding the external pilot specification [R] to the part number.



SMC 3

Series VQZ Base Mounted Replacement Parts

One-touch Fitting Assembly (for Cylinder port)

Fitting size Model	СЗ	C4	C6	C8	C10
VQZ1000	VVQ1000-50A-C3	VVQ1000-50A-C4	VVQ1000-50A-C6	—	—
VQZ2000	—	VVQ1000-51A-C4	VVQ1000-51A-C6	VVQ1000-51A-C8	—
VQZ3000	_	—	VVQ2000-51A-C6	VVQ2000-51A-C8	VVQ2000-51A-C10

Note) Purchasing order is available in units of 10 pieces.



A Caution

When replacing only the pilot valve assembly, use caution because it is not possible to convert to a V115 (DIN terminal) from a V111 (Grommet, L-type, M-type), or vice versa.

Model

VQZ1000	VQZ1000-S-01 🖹 (-Q)
VQZ2000	VQZ2000-S-01 * (-Q)
VQZ3000	VQZ3000-S- ⁰² * (-Q)
* Thread type	

Sub-plate part no.

* Thread type

EX510 Gateway System **Serial Transmission System** Series VQZ1000/2000/3000 **Base Mounted Manifold**

CE [Option]



One-touch fitting (Metric size)

Symbol	Port size	VQZ1000	VQZ2000	VQZ3000
C3	ø3.2 one-touch fitting	0	_	—
C4	ø4 one-touch fitting	0	0	—
C6	ø6 one-touch fitting	0	0	0
C8	ø8 one-touch fitting	_	0	0
C10	ø10 one-touch fitting	—	_	0
СМ	Mixture of port sizes	0	0	0

One-touch fitting (Inch size)

Symbol	Port size	VQZ1000	VQZ2000	VQZ3000
N1	ø1/8" one-touch fitting	0	—	—
N3	ø5/32" one-touch fitting	0	0	—
N7	ø1/4" one-touch fitting	0	0	0
N9	ø5/16" one-touch fitting	—	0	0
N11	ø3/8" one-touch fitting	_	_	0
NM	Mixture of port sizes	0	0	0

SI Unit Part No.

@SMC

Symbol	SI unit spec.	SI unit part no.
Nil	NPN output (+COM.)	EX510-S001
Ν	PNP output (-COM.)	EX510-S101

For details of "Gateway System Serial Transmission System, Series EX510", refer to pages 1696 through to 1724.



is shipped with the valves (including blanking plates) and connector assembly

mounted on it, as the standard specification. Be sure to specify the part nos. of the solenoid valves to be mounted.

Note 2) For details on external pilot type, refer to page 966.



Made to Order

X30

X90

X113

Symbol

Made to Order

(For details, refer to page 975.)

Pilot valve common exhaust

Main valve fluoro-rubber

All fluoro-rubber

Description

Dimensions: VQZ1000-SA : EX510 Gateway System Serial Transmission System



The dashed lines indicate the DIN rail mounting [-D].

Unless otherwise indicated, dimensions are the same as L-type plug connector (L). []: AC

Dimensions

Dimens	sions													Max. 16	stations
L n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	123	123	123	123	123	135.5	148	160.5	173	185.5	198	210.5	223	235.5	248
L2	112.5	112.5	112.5	112.5	112.5	125	137.5	150	162.5	175	187.5	200	212.5	225	237.5
L3	88	88	88	88	88	100	112	124	136	148	160	172	184	196	208
L4	17.5	17.5	17.5	17.5	17.5	17.5	18	18.5	18.5	19	19	19.5	19.5	20	20
L5	80	80	80	80	80	92	104	116	128	140	152	164	176	188	200

Note) The L dimension of 2 to 6 stations is the same. Valves are numbered from the D side according up to the number of stations.



VP4

VQ4

VQ5

VFS

VFR

V07

Dimensions: VQZ2000-SA : EX510 Gateway System Serial Transmission System



L4 17.5 15.5 19.5 16.5 20.5 L5

Note) The L dimension of 2 to 5 stations is the same. Valves are numbered from the D side according up to the number of stations.

L2

L3



287 5

18.5

Dimensions: VQZ3000-SA : EX510 Gateway System Serial Transmission System



The dashed lines indicate the DIN rail mounting [-D].

Unless otherwise indicated, dimensions are the same as L-type plug connector (L). []: AC

Dimensions

Dimens	sions													Max. 16	stations
L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	123	123	148	173	185.5	210.5	223	248	273	285.5	310.5	323	348	373	385.5
L2	112.5	112.5	137.5	162.5	175	200	212.5	237.5	262.5	275	300	312.5	337.5	362.5	375
L3	92	92	112	132	152	172	192	212	232	252	272	292	312	332	352
L4	15.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17	19.5	15.5	18	20.5	17
L5	70	70	90	110	130	150	170	190	210	230	250	170	290	310	330

Note) The L dimension of 2 to 3 stations is the same. Valves are numbered from the D side according up to the number of stations.



Manifold Options

Connector assembly

Single solenoid (SY3000-37-81A-D-N)





Connector Assembly Part No. (for a manifold with 8 stations or less with an unspecified layout) Bar Stock Type

Model	Part no.	Connector mounting position
	SY3000-37-81A-3-N	Single: for 1 to 4 stations
VV5QZ12	SY3000-37-81A-3-6	Double/3 position: for 1 to 4 stations
VV5QZ12	SY3000-37-81A-2-N	Single: for 5 to 8 stations
	SY3000-37-81A-3-6	Double/3 position: for 5 to 8 stations
VV5QZ22	SY3000-37-81A-3-N	Single: for 1 to 8 stations
VV5QZ22	SY3000-37-81A-3-6	Double/3 position: for 1 to 8 stations
	SY3000-37-81A-3-N	Single: for 1 to 4 stations
10/50700	SY3000-37-81A-3-6	Double/3 position: for 1 to 4 stations
VV5QZ32	SY3000-37-81A-4-N	Single: for 5 to 8 stations
	SY3000-37-81A-4-7	Double/3 position: for 5 to 8 stations

Note) There are no part nos. on the connectors of connector assemblies.

Connector assembly

SY3000-37-80A-



Housing (1 set: 8 pieces) SY3000-44-3A



Connector Assembly Part No. (for a manifold with a specified layout)

Model	Part no.	or mounting position	
	SY3000-37-80A-3	A side	
10/50740	SY3000-37-80A-6	B side	For 1 to 8 stations
VV5QZ12	SY3000-37-80A-4	A side	
	SY3000-37-80A-7	B side	For 9 to 16 stations
	SY3000-37-80A-3	A side	Found to O stations
V/VE O7 00	SY3000-37-80A-6	B side	For 1 to 8 stations
VV5QZ22	SY3000-37-80A-7	A side	
	SY3000-37-80A-9	B side	For 9 to 16 stations
	SY3000-37-80A-4	A side	For 1 to 0 stations
V//FO700	SY3000-37-80A-7	B side	For 1 to 8 stations
VV5QZ32	SY3000-37-80A-8	A side	For 0 to 10 stations
	SY3000-37-80A-11	B side	For 9 to 16 stations

Note 1) Since these connector assemblies are used when adding stations or for maintenance, there are no part nos. on them.

Note 2) After inserting the connector assembly into the housing, slightly pull the lead wire to make sure it does not pull out. Do not reuse the lead wire once it has been inserted.

Note 3) Please note that the wires are longer than the actual wiring distance.





Please contact SMC for detailed dimensions, specifications, and lead times.



SJ

1 Pilot Valve Common Exhaust Specification

Pilot exhaust is exhausted through the main R port.

- * Not designed to prevent leakage to outside.
- * A combination of external pilots is not available.
- * A combination of metal seal and 2 position double is not available.
- * "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

Applicable solenoid valve series: VQZ1000/2000/3000 SY SV How to Order SYJ VQZ X30 SZ VP4 Entry is the same as standard products. Made to order S0700 X30 Pilot valve common exhaust VQ Main Valve Fluoro-rubber Specification VQ4 The seal material, the part of the main valve in contact with fluid, is made of fluoro-rubber. * "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve." VQ5 Applicable solenoid valve series: VQZ1000/2000/3000 VQC How to Order VQZ SQ X90 VFS VFR Seal type Made to order VQ7 X90 Main valve fluoro-rubber 1 Rubber seal

Entry is the same as standard products.

3 All Fluoro-rubber Specification

The rubber material of the part in contact with fluid, is made of fluoro-rubber. * "How to Order Manifold" is the same as standard products. Please specify this to "How to Order Valve."

Applicable solenoid valve series: VQZ1000/2000/3000

How to Order





Be sure to read before handling.

Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

Manual Override

A Caution

Without an electric signal for the solenoid valve the manual override is used for switching the main valve. Push type is standard. Locking type (Tool required) is available as an option.

Push type (Tool required)



Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.

Locking type (Tool required)



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.

Locked position

FUSH	
\frown	

Precautions

When operating with a screwdriver, turn it gently using a watchmaker's screwdriver. (Torque: less than 0.1 N•m)

How to Use L/M-Type Plug Connector

A Caution

1. Attaching and detaching connectors

- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.



Light/Surge Voltage Suppressor

▲ Caution

1. L/M-type plug connector <DC>



<AC>



2. DIN terminal

With light/surge voltage suppressor (YS, YOS)



Light/surge voltage suppressor (YZ)







NL: Neon light

Note) Surge voltage suppressor of varistor has residual voltage corresponding to the protective element and rated voltage; therefore, protect the controller side from the surge.

3. Surge voltage countermeasures

When shutting off the DC power supply using an emergency circuit breaker, the valve may operate incorrectly due to surge voltage generated by other electric parts (e.g., the solenoid). To ensure that surge does not affect the valve, take anti-surge measures (diode for surge protection, etc.) or use a valve with diode to prevent reverse current. (Contact SMC for model numbers.)





 (1), (3): Examples of anti-surge measures
 (2): Valve equipped with diode to prevent reverse current





Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

Lead Wire Connection

A Caution

1. Crimping of lead wires and sockets

Not necessary if ordering the lead wire pre-connected model. Strip 3.2 to 3.7 mm at the end of the lead wires, insert the ends of the core wires evenly into the sockets, and then crimp with a crimping tool. When this is done, take care that the coverings of the lead wires do not enter the core wire crimping area.



Crimping tool part no. DXT170-75-1

2. Attaching and detaching sockets with lead wires

Attaching

Insert the sockets into the square holes of the connector (\oplus , \ominus indication), and continue to push the sockets all the way in until they lock by hooking into the seats in the connector. (When they are pushed in, their hooks open and they are locked automatically.) Then, confirm that they are locked by pulling lightly on the lead wires.

Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1 mm). If the socket will be used again, first spread the hook outward.



Valve and Pilot Valve Replacement

A Caution

1. When replacing a conventional type valve with a new type for maintenance or other reasons, a "conversion connector assembly" is necessary to convert the connector from 3 terminals to 2 terminals and must be ordered separately. (When ordering, refer to the below part nos.)

For pilot valves, there is no compatibility between the conventional type and new type. When replacing a pilot valve, be sure to confirm whether it is the new type or the conventional type.





Conversion connector assembly VQZ1

0	0	0	v	-8	5	-L	Δ

	Coil voltage
1	24/12 VDC
2	100 VAC
3	200 VAC
4	Other AC voltages

Pilot valve

(VQ111)

Adapter plate



Be sure to read before handling.

Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

How to Use DIN Terminal

1. Conforming to ISO#: EN-175301-803C (Former DIN 43650C)

(8 mm between pins)

The DIN terminal type with an IP65 enclosure is protected against dust and water, however, it must not be used in water.

2. Connection

- 1) Loosen the holding screw and pull the connector out of the solenoid valve terminal block.
- 2) After removing the holding screw, insert a flat head screwdriver, etc. into the notch on the bottom of the terminal block and pry it open, separating the terminal block and the housing.
- 3) Loosen the terminal screws (slotted screws) on the terminal block, insert the cores of the lead wires into the terminals according to the connection method, and fasten them securely with the terminal screws.
- 4) Secure the cord by fastening the ground nut.

3. Changing the entry direction

After separating the terminal block and housing, the cord entry can be changed by attaching the housing in the desired direction (4 directions at 90° intervals).

* When equipped with a light, be careful not to damage the light with the cord's lead wires.

4. Precautions

Plug in and pull out the connector vertically without tilting to one side.

5. Compatible cable

Cable O.D.: ø3.5 to ø7

(Reference) 0.5 mm², 2-core or 3-core, equivalent to JIS C 3306



DIN Connector Part No.

Without light

White out light		
Rated voltage	Voltage symbol	Part no.
All voltages	None	SY100-82-1

With light

With light		
Rated voltage	Voltage symbol	Part no.
24 VDC	24 V	SY100-82-3-05
12 VDC	12 V	SY100-82-3-06
100 VAC	100 V	SY100-82-2-01
200 VAC	200 V	SY100-82-2-02
110 VAC (115 VAC)	110 V	SY100-82-2-03
220 VAC (230 VAC)	220 V	SY100-82-2-04

Circuit diagram with light



Fitting and Silencer Part No. for P, R Ports When Using Valve as an Individual Unit

Part no. for one-touch fitting for 1(P) port and silencer/one-touch fitting for 3(R2, R), 5(R1) port

intang ioi o(in							
Series	(1) One-touch	(2) For 3(R2	2, R) port, 5(R1) port				
Series	fitting for 1(P) port	Silencer	One-touch fitting				
VQZ1000	KQ2H06-M5	AN120-M5	KJS04-M5				
VQZ2000	KQ2S06-01S	INA-25-46	IN-457-32L (for ø6)				
VQZ3000	KQ2H08-02S	AN101-01	KQ2H06-01S				

The diameter of the above fitting and silencer is the maximum diameter to in the EXH port.





Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

3 Port Valve for Mixture Mounting

1. Body ported (VQ $Z_{3}^{1}82^{\circ}$, N.C./VQ $Z_{3}^{1}92^{\circ}$, N.O.)

Even though 3 port valves have the same construction as the 5 port single solenoid valves, the port plug is installed in the 2(B) port for N.C. type, and 4(A) port for N.O. type. By changing the port plug into a fitting, it can be used as the 5 port single solenoid valves, too.



2. Base mounted (VQZ $\frac{1}{3}$ 85 $^{\circ}_{1}$, N.C./VQZ $\frac{1}{3}$ 95 $^{\circ}_{1}$, N.O.)

3 port valves have the same external appearance as the 5 port valves. When using this type, 4(A) port on the 3 port valves can be used as 4(A) port on the 5 port valves' manifold, too. Besides, there's no problem, even though 2(B) port can be either plugged or unplugged.



When port plug is used on 2 (B) port, indicate CM in manifold part no. and port size, and specify the port plug location by the manifold specification sheet.

One-touch Fittings Replacement

A Caution

The built-in fittings on the manifold can be changed easily. Simply remove the corresponding valve and take out the fitting clip underneath.

Take out the clip with a screwdriver, etc., then replace the fittings. About mounting the fittings, after inserting the fitting until it stops, then put the clip into the prescribed position.



VQZ1000/2000: Horizontally clipped to the valve body VQZ3000: Vertically clipped to the valve body



Precautions

When pulling the fitting assembly away from the valve base, remove the clip, then connect a tube or plug (KQP- $\Box\Box$) with the one-touch fitting and pull it out holding the tube or plug. Do not hold the release bushing to avoid damage.



Be sure to read before handling.

Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

DIN Rail Removal/Mounting

A Caution

1. Removing

- 1) Loosen the clamp screw on the (a) side of both ends of the manifold.
- Lift the ⓐ side ⇒ of the manifold off the DIN rail and slide it in the direction of the ⓑ side.

2. Mounting

- 1) Catch the hook of the DIN rail bracket on the side on the DIN rail.
- 2) Push side (a) onto the DIN rail and tighten the clamp screw. The proper tightening torque for screws is 0.3 to 0.4 N•m.



Valve Mounting

A Caution

1. After confirming the gasket is correctly placed under the valve, securely tighten the bolts with the proper torque shown in the table below.

Model	Proper tightening torque
VQZ1000	0.18 to 0.25 N•m
VQZ2000	0.25 to 0.35 N•m
VQZ3000	0.5 to 0.7 N•m



Serial Wiring EX510 Precautions

Design and Selection

🕂 Warning

Use within the allowable voltage range. Using beyond the allowable voltage range is likely to cause the units and connecting devices to be damaged or to malfunction.

- 2. Do not use beyond the specified range. Using beyond the specified range is likely to cause a fire, malfunction, or breakdown in the units and connecting devices. Check the specifications before handling.
- 3. Establish a backup system beforehand, which employs fail-safe concepts such as multiple equipment and devices to prevent breakage or malfunction of this product.
- 4. Provide an external emergency stop circuit that will immediately stop an operation and cut off the power supply.
- 5. When using for an interlock circuit:
 - Provide a double interlock which is operated by another system (such mechanical protection function).
 - Perform an inspection to check that it is working properly because it can cause possible injuries.





Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

Serial Wiring EX510 Precautions

Design and Selection

A Caution

1. Keep the surrounding space free for maintenace.

When designing a system, take into consideration the amount of free space needed for performing maintenance.

- 2. Use the following UL approved products for DC power supply combinations.
 - 1) Controlled voltage current circuit conforming to UL508 Circuit uses the secondary coil of an isolated transformer as the power supply, satisfying the following conditions.
 - Max. voltage (with no load): 30 Vrms (42.4 V peak) or less
 Max. current: (1) 8 A or less (including shorts), and
 - (2) When controlled by a circuit protector (fuse, etc.) with the following rating

No-load voltage (V peak)	Max. current rating
0 to 20 [V]	5.0
Over 20 [V] to 30 [V]	100
	Peak voltage value

- 2) A circuit (class 2 circuit) with maximum 30 Vrms (42.4 V peak) or less, and a power supply consisting of a class 2 power supply unit confirming to UL1310, or a class 2 transformer confirming to UL1585
- 3. This product is one of the components to be equipped into a final equipment. Confirm the adaptability to the EMC directive as the whole equipment by customers themselves.
- 4. The power supply for the Gateway unit should be 0 V as the standard for both power supply for outputs as well as inputs and for the control unit of the Gateway.



Mounting

▲ Caution

1. Do not drop, bump, or apply excessive impact.

Otherwise, the unit can become damaged, malfunction, or fail to function.

2. Hold the body while handling this product. Otherwise, the unit can become damaged, malfunction, or fail to function.

3. Observe the tightening torque range. Tightening outside of the allowable torque range will likely damage the product.

4. Do not install a unit in a place where it can be used as a scaffold.

Applying any excessive load such as stepping on the unit by mistake or placing a foot on it, will cause it to break.

∧ Warning

1. Avoid miswiring.

If miswired, there is a probability of damaging units or connecting devices.

Wiring

- **2. Do not wire while energizing the product.** It is likely to damage the units or connecting devices.
- 3. Avoid wiring the power line and high pressure line in parallel.

Noise or surge produced by signal line resulting from the power line or high pressure line could cause a malfunction. Wiring of the reduced-wiring system and the power line or high pressure line should be separated from each other.

4. Confirm the wiring insulation.

Inferior insulation (contact with other circuit, insulation between terminals, etc.) will likely cause damage to the units or connecting devices due to excessive voltage or the influx of current.

A Caution

1. Take measures to avoid applying repeated bending force or pulling force to the cable.

Also, pay attention not to place any heavy matter on the cable or clipping. It is likely to cause a broken wire.

2. Confirm grounding to maintain the safety of the reduced-wiring system and for anti-noise performance.

Grounding should be close to units and keep the grounding distance short.



Be sure to read before handling. Refer to front matters 58 and 59 for Safety Instructions and pages 3 to 7 for 3/4/5 Port Solenoid Valve Precautions.

Serial Wiring EX510 Precautions

Operating Environment

\land Warning

- 1. Do not use this product in the presence of dust, particles, water, chemicals, and oil. Use with such materials is likely to cause a malfunction or breakage.
- 2. Do not use this product in the presence of a magnetic field.

Use in such an environment is likely to cause a malfunction.

3. Do not use this product in an atmosphere containing an inflammable gas, explosive gas, or corrosive gas.

Use in such an atmosphere is likely to cause a fire, explosion, or corrosion.

This reduced-wiring system is not explosion-proof.

4. Do not use this product in places where there are cyclic temperature changes. In case that the cyclic temperature is beyond normal tempera-

In case that the cyclic temperature is beyond normal temperature changes, the internal unit is likely to be adversely effected.

5. Do not use this product in places where there is radiated heat around it.

Such a place is likely to cause a malfunction or breakage.

6. Do not use this product near sources that generate a surge which exceeds the benchmark test, even though this product is CEmarked certified.

The internal circuit components are likely to deteriorate or become damaged when there are equipment (solenoid type lifter, high frequency guided furnace, motor, etc.) which generate a large surge around the reduced wiring system. Take measures to prevent an electrical surge and avoid having the wires touch each other.

7. Use the product type that has an integrated surge absorption element when directly driving a load which generates surge voltage by relay or solenoid valves.

8. The reduced wiring system should be installed in places with no vibration or shock. If installed in a place with vibration or shock, a malfunction or breakage is likely to occur.

Adjustment and Operation

A Warning

1. Do not short-circuit a load.

If a load is short-circuited, excessive can cause damage to the connected devices. The fuse of the input unit will melt and below. The output and SI unit will activate its overcurrent protection function. However, they cannot cover all modes, so damage is likely to occur.

2. Do not manipulate or perform settings with wet hands.

Performing such activity will likely cause an electrical shock.

A Caution

1. DIP switches and rotary switches should be set with a small watchmaker's screwdriver.

Maintenance

\land Warning

1. Do not disassemble, modify (including circuit board replacement) or repair this product.

Such actions are likely to cause injuries or breakage.

- 2. Perform periodic inspection. Confirm that wiring or screws are not loose. Otherwise, unpredicted malfunction in the system composition devices is likely to occur.
 2. When an inconcetion is performed.
- 3. When an inspection is performed.
 - Turn off the power supply.

• Stop the supplied fluid and discharge the fluid in the piping and confirm the release to the atmosphere before performing an inspection. It is likely to cause injuiries.

▲ Caution

1. Do not wipe this product with chemicals such as benzine or thinner.

Using such chemicals is likely to cause damage.